

Operation instructions

LLC Pulsar-Telecom


195009, Russia, Saint-Petersburg, Bobruiskaya str.,7
Tel.: (812) 703-77-65, 542-04-80
Fax: (812) 542-11-85

105122, Russia, Moscow, Schelkovskoye Highway, 2,
office 225
Tel./fax: (495) 580-37-61, 78-77-066

www.ironlogic.ru

 Certificate GOST R No POCC RU.ME83.B00374

iron  Logic



**MATRIX-III
RD-ALL**

iron  Logic

Reader

Table 2. Connection. Output RS 232 (Cable No 2), Output RS 485 (Cable No 3).

Wire color	Purpose	
RS232 (Cable No 2)		
blue	RxD (contact 2 connectors DB9 COM)	
yellow	TxD (contact 3 connectors DB9 COM)	
black	Sig Earth (contact 5 connectors DB9 COM)	
RS485 (Cable No 3)		
(to connect to PC we recommend to use converter USB-485 Z-397)		
blackA	A input to "A" of converter	
blue	B input to "B" of converter	
red	A output	To connect external load 120 Ohm
yellow	B output	

2. CHARACTERISTICS

Identification cards: cards of EM-Marine, HID (Prox Card II), MIFARE standard
Autodetection of card standard without additional settings.
Reading distance for cards/keyfobs - 2-10cm:
Output protocol: -Dallas Touch Memory -Wiegand-26 RS232, RS485
Remoteness of reader from controller in DS1990A mode, not exceeding 15m
Remoteness of reader from computer in Wiegand mode, not exceeding 100m
Remoteness of reader from computer in standard RS 232, not exceeding 5m
Remoteness of reader from computer in standard RS 485, not exceeding, 1200m (we recommend to use converter USB-485 Z-397)
Confirmation of card reading: buzzer signal, two-color light-emitting diode
Power voltage: 9 - 16 V DC
Current consumption in standby card mode, not exceeding: 80 mA
Operation temperature (indoor): from -40°C to + 50°C
Relative humidity, not exceeding: 95 %
Size: 115x75x22 mm.
Execution: attachable body frame with cover. The scheme is filled with compound.




Fig.4. Connection diagram

3. READER OPERATION

Reader operation without external indication management (internal indication):

1. When there is no card in the reader field red light-emitting diode is always on.
2. When you swipe the card red light-emitting diode is off and green diode flashes and short sound signal is given.
3. There is no light indication when the card is in the field.

External management with red, green light diode and sound is performed by short circuit to common contact (active "0"). External indication may be used together with internal indication, i.e. external management excludes only the channel managed from external devices.

Read card number is transferred to exit -Dallas Touch Memory -Wiegand-26 RS232, RS485. When the reader is connected to PC through RS232 or RS 485 the name of card standard and number in Wiegand26 format is shown in the window of Hyper Terminal program. For serial ports you should setup the following communication parameters: speed 9600, bit-8, parity-no, stop bits-1, flow control no.

To display the product data program (serial number) press button at the PC keyboard "I". Each reader has its own serial number used when FirmWare product is updated by user in RS232 standard.

The MATRIX-III RD-ALL S/N:00111 (00DE)
CopyRight (C)2006 IronLogic, Saint-Petersburg, RUSSIA
www.ironlogic.ru ph. +7(495)78-77066,+7(812)542-04-80
Please send Email: marketing@ironlogic.ru
Software version: 0001
Em-Marine[1901] 034,00032
No Card
Mifare[497F0280046CDD] UL (0144,00) 004,27869
No Card
Mifare[22C37BB0] 1K (0004,08) 195,31664
No Card
HID[0010039B] 22553
No Card

Reader serial number 00111
Each reader has its own serial number.
It is required when FirmWare product
is updated by user in RS232 standard.

Fig.2. HyperTerminal.

4. INSTALLATION AND CONNECTION

Install the reader at flat surface in a place providing free swipe of PROXIMITY cards.
To install the reader "MATRIX-III"RD-ALL proceed as follows:

1. Remove upper cover.
2. Mark and drill holes to fix the reader.
3. Get cable from reader into the hole and connect wires in accordance with scheme.
At the junctions insulate wires.
4. Install cable. Turn on power and check reader operation.
When the power is on, red light-emitting diode at the reader turns on.
5. Install reader and fix it with bolts.
6. Install and fix upper cover.

5. DELIVERY SET

- Reader "MATRIX-III"RD-ALL -1 pc.
- Screw 3x30- 2pcs.
- Dowel pin 2pcs.
- Operation instructions 1pc




Fig.3. Overall dimensions




Fig.1 The connection scheme MATRIX-III-RD-ALL.

Table 1. Connection to controller (Cable No1)

Connection to controller			
Wire color	Connection by Wiegand26	Connection Dallas Touch-Memory (emulation)	Connection Dallas Touch-Memory (single transition)
red	+12 V	+12 V	+12 V
black	Common (minus)	Common (minus)	Common (minus)
white	DATA 0	TM (central)	TM (central)
brown	DATA 1	Common (minus)	TM (central)
green	LED-G (external management with green)		
yellow	LED-R (external management with red)		
blue	BEEP (external management with sound)		

1. GENERAL

Designed for operation in ACS, payment and other systems using non-contact cards.

Reader features:

- reads codes of cards 125Khz and 13.56MHz -EM-Marine, HID(ProxCard II), Mifare (Muskovite's Social Card, underground and railway systems cards, etc.)
- autodetection of card standard without additional setup and number transfer by Wiegand 26, Touch Memory, RS232, RS485
- possibility of "FirmWare" update by user by RS232, RS485.

6. WARRANTY

Warranty period is 18 months from the date of sale but not exceeding 24 months from date of manufacture.

Reasons for warranty termination:

- violation of these Instructions and maintenance requirements;
- mechanical damages;
- use of aggressive agents;
- unauthorized intervention into the scheme.

During the warranty period the Manufacturer repairs reader failures free of charge which appeared due to the fault of Manufacturer or replaces faulty components and blocks. Repair is performed in the Manufacturer workshop.

Date of sale: " ____ " _____ 200__ r.

Distributor _____